


# How to clean a plasma screen

Many Plasma TVs have a special low reflective coating on the front of the glass screen. While this coating serves a useful purpose, it is important to take care not to scratch or otherwise damage the coating when cleaning the screen.

- Only ever use a soft, clean, lint free cloth to clean the screen.
- Always Switch off the unit when cleaning it
- Use a cloth dry to gently wipe dust from the screen.
- To remove fingerprints etc. you will need two cloths. Make the first cloth damp with a very mild detergent solution (1 part washing up liquid to 100 parts warm water). Thoroughly wring out the cloth so that no liquids can run out (slightly damp only – not wet !)
- Use the damp cloth to gently wipe a small area of the screen and immediately polish off the damp area with a dry cloth in a circular motion until completely dry.
- On larger screens it will be necessary to clean small areas of the screen at a time.



Solution: 1 part detergent to 100 parts warm water



Wipe small areas with a slightly damp cloth in a circular motion and polish dry with a soft dry cloth

# How to clean a plasma screen

The special anti-reflective coating applied to Plasma screens is fragile and can easily be damaged by incorrect cleaning. To prevent damage avoid the circumstances given below.

Never use any solvents or cleaning products, other than the mild detergent solution described. Many household products will damage the coating.

Purchase new soft lint free cloths and keep them for cleaning the screen only. Do not use cloths used for general household cleaning as they may contain residues of chemicals that may damage the special coating.

Never clean the screen with a dirty cloth. Household dust can be abrasive and scratch the coating. Clean the cloths regularly and keep them separate from other cleaning cloths.

Never allow abrasives to come into contact with the screen.

Never try to scratch anything off the glass as even a fingernail can scratch the coating. Use the solution and cloths to remove the substance as described. If it cannot be removed please consult a DSN Service Centre.


Do NOT use proprietary glass cleaning products as some of them can contain chemicals that will damage the coating.

Do NOT use products in spray cans near the screen. Products such as insect repellents, hairspray, deodorants, hand creams, household spray polish and even sun cream can damage the coating. Should any contaminants come into contact with the screen, consult a DSN Service Centre.

Accidental damage to the screen and screen coating is NOT covered by the manufacturer's warranty.



Solution: 1 part detergent to 100 parts warm water



Wipe small areas with a slightly damp cloth in a circular motion and polish dry with a soft dry cloth