


Power On Preference

Power On Preference can automatically select an AV input from an external AV device, such as a Sky Receiver or DVD Recorder connected to the TV via Scart, instead of a TV Programme. This saves having to select the AV Input manually after the TV is switched on.

Select

Press

You will see



- When the TV is switched it will automatically select the AV Input (if the connected device is switched on and producing an output signal). This means that a sky broadcasts etc. can be automatically viewed when the TV is switched on after the sky receiver.

- A Fully wired Scart lead must be used for this to work.

- Where more than one external device is connected and switched on, **AV1** takes priority.